















































Measuring Piston Diameter

- piston diameter is measured at 90 degrees to the piston pin on the piston skirt
- check the service manual the specific engine you working with



Piston rings should be inspected for abnormal wear and are normally replaced any time the piston is removed the piston's ring grooves should also be checked for proper side clearance









