

























Computer Balancing a Tire

- Check the condition of the tire and wheel
- Check the tire's air pressure
- Carefully follow the equipment manufacturer's operating instructions





Cooling System Inspection

- Check coolant level and condition
- Check coolant protection level with a hydrometer
- Inspect the vehicle for any trace signs of coolant leakage
- Pressure test the cooling system if leaks are suspected



Inspecting and Replacing Hoses

· Inspect all hoses for:

Introduction to Automotive Service

- swelling
- soft spots
- hard spots
- cracking
- Carefully remove old hose to prevent damaging radiator or heater core
- Lubricate new hoses before installation



Accessory Drive Belt Types

- V drive belts
 - commonly used to drive one accessory
 - manually adjusted
- · Serpentine drive belts
 - one belt is often used to drive all accessories
 - an automatic belt tensioner may be used



Belt Inspection and Adjustment

- · Inspect the belts for
 - damage
 - cracking
 - · glazing
 - proper tension
- Adjustments are commonly made by loosening bolts and moving the driven accessory or an idler pulley

